



NOTE: ROUGH OPENINGS SHOULD BE FLASHED WITH AN APPROPRIATE MOISTURE BARRIER IN ACCORDANCE WITH INDUSTRY STANDARDS AND/OR BUILDING CODES. PERIMETER CAULK WINDOW FRAME TO MOISTURE BARRIER AFTER INSTALLATION.

- 1) OPEN THE VENT SASH AS NEEDED AND DRILL  $\frac{3}{16}$ " HOLES IN INTERIOR JAMBS @ MAX. 12" O.C., WITH THE FIRST SCREW AT 6" FROM THE CORNER OF THE FRAME. COUNTERSINK HOLES SO THAT HEAD OF SCREW WILL NOT INTERFERE WITH OPERATION OF VENT SASH. (RECOMMENDED SCREW TYPE 10-3 $\frac{1}{2}$  FLAT HEAD)
- 2) PLACE WINDOW IN OPENING. WINDOW SILL SHOULD SIT LEVEL WITH FULL BEARING ON STRUCTURAL SILL.
- 3) CENTER WINDOW IN OPENING. VERIFY PLUMB AND LEVEL CONDITION OF WINDOW, MAKING SURE THE REVEAL IS EQUAL.
- 4) SHIM WINDOW ABOVE OR BELOW ALL ANCHOR POINTS. VERIFY PLUMB & LEVEL.
- 5) SECURE JAMBS WITH SCREWS AT PRE-DRILLED HOLES TO SECURE WINDOW JAMBS TO STRUCTURE WITH APPROPRIATE LENGTH OF SCREWS.
- 6) RECHECK PLUMB & LEVEL CONDITION OF WINDOW.

\*\* WHEN EXTERIOR WALL FINISH IS COMPLETED - PERIMETER CAULK TO WINDOW FRAME. \*\*